


Size: 5.9" X 8.3"

HOW TO INSERT THE BATTERIES

- Your product requires 3PCS LR44 batteries, not included.
- Press the tab on the battery compartment lid and lift lid upward to remove.
- Install 3PCS LR44 batteries, then close the battery compartment.
- Easy on - off switch.



LED MAINTENANCE

- For indoor/covered outdoor use.
- Clean with a soft cloth.

CAUTION

- The cork led is not a toy and should be kept out of reach of children.
- Failure to insert batteries in the correct polarity, as indicated may shorten the battery life or may cause leakage.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium or nickel metal hydride) batteries.
- Remove batteries if consumed or if product is to be left unused for a long period of time.