

Instructions for Vino Voyage 2.0 Weighing Handle:



Turning your scale on and off: To start your weighing scale quickly press the button located by the scale. In order to shut down your scale press the same button for about 2 seconds, then the LED screen will turn off.

Weight Range: Maximum weight- 66LBS, Minimum weight- 4.41LBS. If the weight does not fall within the weight range an "ERR" will appear on the LED screen display.

How to use the scale: Put the Vino Voyage on the ground smoothly, press the button located near the LED screen. The screen will display "KG", and then turn to "0.0"; When the screen reflects "0.0", lift the handle of the Vino Voyage to start weighing your luggage. Hold still, then the LED screen will show the real-time weight and automatically lock. After displaying the weight for 12 seconds the handle will automatically shut off. The handle will also automatically shut off if you wait more than 12 seconds to weigh your luggage in the "0.0" state.

Batteries used-Standard button batteries are used: $1.5V \times 2 = 3V$ (A76/LR44). When "lo" is displayed on the LED screen, that means it's time to change the batteries.

How to change the batteries:

1. Remove the wine inserts from the luggage.
2. Unzip the lining of the luggage.
3. Look for the storage lid where the batteries are currently stored. (see image below)



4. Take the lid off; and remove dead batteries.
5. Insert two button cell batteries and close the lid.
6. Repeat steps if batteries die again.

Unit: The Vino Voyage weighs in both KG and LB

How to change unit conversion: Press the button to start the handle, and the LED screen will display "KG". Press the button again to display "LB", then press the button a third time to display "KG". After selecting the required unit, the screen will display "0.0". Once you select a unit of measurement the next time you use the scale it will be automatically set to the selected unit.

Note: Please dispose of the batteries in a proper manner to avoid accidental ingestion by children.

TSA-Accepted Luggage Locks

- Ideal for air travel - features the TSA - recognized *Travel Sentry*® logo
- Allows airport screeners to unlock, inspect and relock bags, without damaging the lock
- For more information on the *Travel Sentry*® Approved override system, please visit www.travelsentry.org



TRAVEL SENTRY®
APPROVED



TSA-371

INSTRUCTIONS

The original number is 0-0-0. To set your personal combination, follow these steps:

1. Put the discs at its original numbers 0-0-0.
2. Press down the reset button (a) with a tool until hear the "click" sound.
3. Set your combination by turning the discs (b). For example 8-8-8. Then,
4. Push the button (c) towards to the direction of arrow and the reset button (a) will be back when you hear the "Click" sound. Now you have finished to set your personal combination. Please remember your personal combination by heart. Please repeat the above steps to reset the number.

WARNING:

If the cylinder is opened, pls pay attention to lock it again by turning it to the red dot position by the direction of the arrow. Any tool which can be inserted in the cylinder is OK.

